

TABLE OF CONTENTS

INTRODUCTION	1
---------------------------	----------

PART ONE: ABOUT REMOTE CONTROL.....**3**

CHAPTER ONE: OVERVIEW	5
------------------------------------	----------

Operate WavePro by Remote Control	5
STANDARDS.....	6
PROGRAM MESSAGES.....	6
COMMANDS AND QUERIES.....	7
HEADERS.....	8
HEADER PATHS.....	8
DATA.....	9
CHARACTER DATA.....	9
NUMERIC DATA.....	9
STRING DATA.....	10
BLOCK DATA.....	10
RESPONSE MESSAGES.....	10
USE SCOPEEXPLORER?	11

CHAPTER TWO: CONTROL BY GPIB	13
---	-----------

Talk, Listen or Control	13
INTERFACE	13
ADDRESS.....	14
GPIB SIGNALS.....	14
I/O BUFFERS.....	14
USE IEEE 488.1 STANDARD MESSAGES.....	15
DEVICE CLEAR.....	15
GROUP EXECUTE TRIGGER.....	15
REMOTE ENABLE	15
INTERFACE CLEAR.....	16
CONFIGURE THE GPIB-DRIVER SOFTWARE	16
MAKE SIMPLE TRANSFERS.....	17
USE ADDITIONAL DRIVER CALLS	19
MAKE SERVICE REQUESTS.....	19
Take Instrument Polls	21
DO CONTINUOUS POLLING.....	21
TAKE A SERIAL POLL.....	21
DO A PARALLEL POLL.....	22
PERFORM AN *IST POLL.....	24

TABLE OF CONTENTS

Drive Hard-copy Devices on the GPIB.....	25
READ DATA BY CONTROLLER.....	25
SEND DATA TO BOTH	25
TALK DIRECTLY TO PRINTER.....	26
CHAPTER THREE: CONTROL BY RS-232.....	29
Communicate through the RS-232-C Port.....	29
HANDSHAKE CONTROL.....	29
EDITING FEATURES.....	30
MESSAGE TERMINATORS.....	30
SRQ MESSAGE.....	31
LONG LINE SPLITTING.....	31
REMARKS.....	32
Simulate GPIB Messages.....	33
CHAPTER FOUR: UNDERSTAND AND MANAGE WAVEFORMS.....	35
Know Your Waveform.....	35
LOGICAL DATA BLOCKS.....	35
INSPECT WAVEFORM CONTENTS.....	36
USE THE WAVEFORM QUERY	37
INTERPRET VERTICAL DATA.....	39
CALCULATE A DATA POINT'S HORIZONTAL POSITION.....	40
USE THE WAVEFORM COMMAND.....	42
Transfer Waveforms at High Speed.....	43
CHAPTER FIVE: CHECK WAVEFORM STATUS	45
Use Status Registers.....	45
OVERVIEW.....	45
STATUS BYTE REGISTER (STB).....	47
STANDARD EVENT STATUS REGISTER (ESR)	47
STANDARD EVENT STATUS ENABLE REGISTER (ESE)	48
SERVICE REQUEST ENABLE REGISTER (SRE).....	48
PARALLEL POLL ENABLE REGISTER (PRE).....	48
INTERNAL STATE CHANGE STATUS REGISTER (INR).....	48
INTERNAL STATE CHANGE ENABLE REGISTER (INE).....	49
COMMAND ERROR STATUS REGISTER (CMR).....	49
DEVICE DEPENDENT ERROR STATUS REGISTER (DDR).....	49
EXECUTION ERROR STATUS REGISTER (EXR).....	49
USER REQUEST STATUS REGISTER (URR).....	49

PART TWO: COMMANDS	51
Use WavePro Commands and Queries	53
COMMAND NOTATION	53
Table of Commands and Queries – By Short Form	55
Table of Commands and Queries – By Subsystem.....	59
APPENDIX I, GPIB PROGRAM EXAMPLES.....	275
Example 1	275
USE THE INTERACTIVE GPIB PROGRAM “IBIC”	275
Example 2.....	276
USE THE GPIB PROGRAM FOR IBM PC (HIGH-LEVEL FUNCTION CALLS).....	276
Example 3.....	280
USE THE GPIB PROGRAM FOR IBM PC (LOW-LEVELFUNCTION CALLS).....	280
APPENDIX II, WAVEFORM TEMPLATE.....	283
Waveform Template.....	283
INDEX.....	295

BLANK PAGE