

SLAC/AP110
January 1998

Generalized Impedances and Wakes in Asymmetric Structures¹

S. Heifets, A. Wagner*, B. Zotter*

*Stanford Linear Accelerator Center, Stanford University, Stanford, CA
94309, USA*

¹Supported by Department of Energy contract DE-AC03-76SF00515.

* Visitor from CERN/SL-AP, CH-1211 Geneva 23

1 Introduction

In most applications to particle accelerators, impedances and wake functions are defined for test and exciting charges traveling on the same trajectory, parallel to the axis of the structure. It is assumed that the velocity of the charges is ultra-relativistic ($v = c$), and both the velocity and the trajectory remain unchanged by the EM fields excited by the charged particles themselves. This definition is quite satisfactory for beams in rotationally symmetric structures, such as rf cavities with circular cross section. In such geometries, the electro-magnetic (EM) fields can be expanded into azimuthal harmonics proportional to $\cos(m\phi)$ or $\sin(m\phi)$. The strongest longitudinal impedance is produced by the uniform harmonic ($m = 0$), and is independent of the offsets of both charges. The strongest transverse impedance is generated by the dipole harmonic ($m = 1$), and is proportional to the offset of the exciting charge, but does not depend on the offset of the test charge. For particle beams near the axis, higher harmonics can usually be neglected. The same considerations hold for the wake functions.

Some elements used in particle accelerators are not rotationally symmetric, although they still have a well defined axis. Examples are vacuum chambers with elliptic or rectangular cross sections, and symmetrically disposed plates on two or four sides of a beam, used e.g. for pickups or separators. In such structures the impedances become dependent also on the offset of the test charge. In this case it is necessary to define generalized impedances, which take into account arbitrary offsets of the trajectories of both the exciting and the test charge from the axis. In structures with even less symmetry, such as pumping slots not distributed uniformly around the vacuum chamber, or one-sided collimators and cavities, it is even not always possible to uniquely define an axis. However, impedances and wake functions can still be obtained by integrating the EM fields along straight lines parallel to the beam trajectory, for various transverse positions of the test and exciting charge. Again the same considerations hold for the wake functions.

The concept of generalized impedances with different trajectories for source and field particles has been introduced already many years ago for the purpose of measuring impedances[1]. A similar generalization can be made for wake functions or wake potentials in the time domain. Due to the more complex geometry of axially non-symmetric structures, the EM fields can be calculated analytically only in very few of them. Expressions in closed form are known for the impedance of elliptic beam pipes with fi-

nite wall resistivity[2]. For the same case, the wake potentials of Gaussian bunches have been given in integral form[3], but the integrals can only be evaluated numerically[4]. It is also possible to express the impedance of a resistive pipes with arbitrary cross section in terms of its electrostatic capacitance, and the impedance of a resistive pipe with rectangular cross section has been obtained in closed form in that manner[5].

From numerical results for transverse wake potentials and loss factors of Gaussian bunches in axially non-symmetric structures it was deduced that they can be separated into dipolar components, proportional only to the offset of the exciting charge, and quadrupolar components, proportional only to the offset of the test charge. Higher-order components are small near the axis and can usually be neglected. In rotationally symmetric structures, the quadrupolar component vanishes and only the dipolar term remains.

The deflection of a charged particle in a dipolar wake potential, as in the case of circular symmetric structures, is always defocusing, i.e. deflecting the beam further out from its radial position. However, in a quadrupolar wake it is defocusing in one transverse direction, but focusing in the orthogonal one. This property is used e.g. in the CLIC focusing scheme with so-called *rf quadrupoles*. The original proposal[6] had axially non-symmetric, elongated beam-hole slots in circular cylindrical cavities, but for technical reasons the geometry was changed to circular beam holes in elliptical cavities.

The dipolar and quadrupolar wake potentials are proportional to the offsets of the leading or the trailing charge. It is therefore sufficient to compute them for unit offset, and multiply them with the values of the actual offsets. They can be pre-calculated and stored in three one-dimensional tables, one for each spatial dimension. This can be done for any bunch shape - in particular for a that of a *basis function*[7] which may be used to describe arbitrary distributions. This is very useful for the simulation of collective effects in circular accelerators or storage rings, which require knowledge of the wake potentials of bunches which are in general distorted and displaced in all directions. It would be much too slow to compute their wake potentials for different offsets on every turn, but they can thus be obtained very quickly from look-up tables containing the longitudinal, dipolar and quadrupolar wake potentials with unit offset for a structure, or even for all elements forming the vacuum chamber[8].

2 Asymmetric Vacuum Chamber Elements

Effective wake potentials, in similarity to *effective impedances* can be defined as integrals over the product of wake potentials and the distribution function, hence they are the same as the loss or kick factors. In the transverse directions, they have two components which we choose as x and y in Cartesian coordinates. In not-axially symmetric structures, they are in general functions of the positions of both the exciting bunch and of the test charge. In structures with enough symmetry to define an axis, e.g. with two orthogonal planes of symmetry, the offsets are measured from this axis. Near this axis, the wake potentials are essentially superpositions of dipolar fields, proportional to \cos or $\sin \phi$, and quadrupolar components, proportional to \cos or $\sin 2\phi$. Higher order components are small, as can be seen in the attached figures for two different LEP components.

Figs.1 a-d show as vector fields the x and y components of the effective transverse wake potentials (kick factors) of a Gaussian bunch with $\sigma = 10\text{mm}$ in the *shielded LEP bellows*. These have an oval cross section, with two orthogonal planes of symmetry, but an asymmetrically tapered profile in the longitudinal direction. The kick factors are plotted as functions of the offsets of the test charge for 4 different beam positions: 1a) centered, 1b) and 1c) offset by 4 mm in x , respectively in y , and 1d) offsets in both the x and y directions. The centered bunch excites an almost pure quadrupolar component, while the offset bunches yield more complicated field patterns.

In Figs.2 a-d, the quadrupolar component (Fig.1a) has been subtracted from the total vector field. Hence the first picture, for a centered bunch, is identically zero as it is subtracted from itself. For the displaced bunches, the residual kick factors are essentially dipolar fields. The vectors are nearly constant in length, and parallel to the displacement of the exciting bunch, i.e. they are independent of the position of the test beam. They are furthermore proportional to the distance of the exciting beam from the axis. As can be seen, there is only little distortion of these dipolar fields due to the admixture of higher-order components. They can usually be neglected in the neighborhood of the axis, where the beams are generally located in particle accelerators and storage rings, in order to minimize particle losses.

Figs. 3 and 4 show the same plots of kick factors for the LEP separators. These consist of two parallel plates, disposed symmetrically above and below the axis of a widened circular vacuum chamber with longitudinally symmetric, tapered side walls. The offsets here are slightly larger (50 mm), but the

separation into dipolar and quadrupolar components is still quite accurate. The dipolar components are in general proportional to the distance of the exciting beam from the axis, and independent of the test beam offset.

In rotationally symmetric structures, it is well known that the transverse wake vanishes completely for centered beams, hence the quadrupolar component is zero. The wakes have only dipolar components, plus some weaker higher-order terms which can usually be neglected near the axis.

In previous computations of transverse kicks due to wake potentials, only dipolar components have been taken into account. While this is admissible for the wakes due to rotationally symmetric structures, it can lead to incorrect results in structures which lack that symmetry. Then it is important to include the quadrupolar components which are often of the same order of magnitude as the dipolar terms.

Here we present an analytic approach to the calculation of the dependence of wake potentials on offsets in structures with and without rotational symmetry. The resulting expressions permit estimates of the importance of the higher-order field components which are often neglected without justification. They also permit quick verification of numerical results which are difficult and/or time consuming to obtain. In particular, the computation of wake potentials of short bunches in large structures without axial symmetry is often limited by memory space, or requires excessive computing times, even with the fastest computers presently available.

3 Cylindrical Symmetric Structures

First we recapitulate the dependence of impedances on offsets (r_0, ϕ_0) of an ultra-relativistic particle beam ($v = c$) in a cylindrically symmetric structure, and on the coordinates (r, ϕ) of the trailing particle, where the integration over the fields is performed:

$$Z_{\parallel}(\omega, r, \phi, r_0, \phi_0) = \int_{-\infty}^{\infty} dz e^{-ikz} E_z(\omega, r, \phi, z, r_0, \phi_0) . \quad (1)$$

The impedance must satisfy the *causality condition*:

$$Z_{\parallel}(\omega, r, \phi, r_0, \phi_0) = Z_{\parallel}^*(-\omega, r, \phi, r_0, \phi_0) . \quad (2)$$

3.1 Synchronous Field Component

The effects of EM fields traveling at speeds different from the beam velocity, $v = \beta c$, average to zero. Hence the impedance is given entirely by the synchronous component of the EM field[9]. In frequency domain these fields are proportional to e^{ikz} . We will split the total field $E_z(\omega)$ into a *synchronous component* E_z^{syn} and the rest \mathcal{E}_z

$$E_z(\omega, r, \phi, z, r_0, \phi_0) = \frac{1}{L} E_z^{syn}(r, \phi, r_0, \phi_0) e^{ikz} + \mathcal{E}_z(\omega, r, \phi, r_0, \phi_0) , \quad (3)$$

where \mathcal{E}_z is assumed to be orthogonal to e^{ikz} when the range of integration $L \rightarrow \infty$, and thus is *not* synchronous with the beam. The impedance is then given by

$$Z_{\parallel}(\omega, r_0, r, \phi_0, \phi) = E_z^{syn}(r, r_0, \phi, \phi_0) . \quad (4)$$

The dependence of E_z^{syn} on r can be found from the fact that both terms in Eq. (3) have different dependences on z , and therefore they have to satisfy the wave equation independently. For the synchronous component, the wave equation is reduced to the *Laplace equation*:

$$\Delta_{\perp} E_z^{syn}(r, \phi, r_0, \phi_0) = 0 \quad (5)$$

for $r \neq r_0$. Hence, the non-singular solution is given by

$$Z_{\parallel}(\omega, r, \phi, r_0, \phi_0) \propto E_z^{syn}(r, \phi, r_0, \phi_0) \propto r^m e^{im\phi} . \quad (6)$$

3.2 Taylor Expansion

The impedance can be expanded into a power series in the offset of the trailing particles, normalized to a typical transverse dimension of the vacuum chamber. Because the eigen-functions are not singular, the expansion starts in general with a constant term:

$$Z_{\parallel}(\omega, r, \phi, r_0, \phi_0) = \sum_{m \geq 0} C_m(r_0, \phi_0) r^m e^{im\phi} + cc , \quad (7)$$

where cc stands for the complex conjugate. Also the coefficients $C_m(r_0, \phi_0)$ can be expanded into a Taylor series to get the double series:

$$Z_{\parallel}(\omega, r, \phi, r_0, \phi_0) = \sum_{m \geq 0} \sum_{k \geq 0} C_{mk} r_0^k r^m e^{i(m\phi - k\phi_0)} + cc . \quad (8)$$

Since the EM fields in an axisymmetric structure depend only on the difference $\phi - \phi_0$, also the impedance must have that dependence. Therefore all coefficients with $k \neq m$ vanish, and one obtains the single series:

$$Z_{\parallel}(\omega, r, \phi, r_0, \phi_0) = \sum_{m \geq 0} C_{mm} r_0^m r^m e^{im(\phi - \phi_0)} + cc . \quad (9)$$

For small offsets, the main contribution is given by the lowest order terms in the expansion. The dominant longitudinal impedance is given by the $m = 0$ term C_{00} , which is independent of all offsets.

The transverse (radial) impedance is obtained by taking the derivative w.r.t. the field coordinate r . Hence

$$Z_{\perp}(\omega, r, \phi, r_0, \phi_0) = \sum_{m \geq 1} C_{mm} m r^{m-1} r_0^m e^{im(\phi - \phi_0)} + cc . \quad (10)$$

The lowest non-vanishing term is for $m = 1$, i.e. the dipolar component, and the dominant *transverse impedance* is:

$$Z_{\perp}(\omega, r, \phi, r_0, \phi_0)^{(m=1)} = C_{11} r_0 e^{i(\phi - \phi_0)} + cc . \quad (11)$$

It can be seen that the dipole impedance is independent of the radial displacement r of the trailing particle, but proportional to that of the leading one r_0 . However, unless the two particles are in the same azimuthal plane, it also depends on the difference of the azimuthal angles $(\phi - \phi_0)$.

3.2.1 Longitudinal Symmetry

Additional constraints exist if the structure has certain symmetries.

For structures longitudinally symmetric w.r.t the (x, y) plane, i.e. which remain unchanged for $z \rightarrow -z$, the impedance must be the same when the offsets of the leading and trailing particles are interchanged:

$$Z_{\parallel}(\omega, r, \phi, r_0, \phi_0) = Z_{\parallel}(-\omega, r_0, \phi_0, r, \phi) . \quad (12)$$

This relation is actually an expression of time reversibility for symmetric structures. In general, time reversibility relates impedances of two structures which are mirror reflected w.r.t. the (x, y) plane. This property was used before to prove the independence of impedances on the direction of particle motion through a structure which is not longitudinally symmetric.

A consequence of this symmetry is that the expansion coefficients must fulfill the relation $C_{mm}(-\omega) = C_{mm}^*(\omega)$.

4 Rotationally Non-symmetric Structures

The electric field strength can be written as a double Fourier transform

$$E_z(\vec{r}, \vec{r}_0, t) = \int_{-\infty}^{\infty} \frac{d\omega dq}{(2\pi)^2} [A(\omega, q, \vec{r}, \vec{r}_0) + A^*(-\omega, -q, \vec{r}, \vec{r}_0)] e^{i(qz - \omega t)}, \quad (13)$$

where we write $\vec{r} = (x, y)$ and $\vec{r}_0 = (x_0, y_0)$ for short.

4.1 Impedance

The synchronous component with $q = k = \omega/c$ is then

$$E_z^{syn}(\vec{r}, \vec{r}_0, t) = [A(\omega, k, \vec{r}, \vec{r}_0) + A^*(-\omega, -k, \vec{r}, \vec{r}_0)] e^{i(kz - \omega t)}, \quad (14)$$

and defines the longitudinal impedance:

$$Z_{||}(\omega, \vec{r}, \vec{r}_0) = A(\omega, k, \vec{r}, \vec{r}_0) + A^*(-\omega, -k, \vec{r}, \vec{r}_0). \quad (15)$$

The causality condition

$$Z_{||}(\omega, \vec{r}, \vec{r}_0) = Z_{||}^*(-\omega, \vec{r}, \vec{r}_0) \quad (16)$$

is then fulfilled automatically. The synchronous field component has to fulfill the wave equation $(\Delta + k^2) E_z^{syn} = 0$, hence $\Delta_{\perp} Z_{||}(\omega, \vec{r}, \vec{r}_0) = 0$. Since the impedance must be a solution of the Laplace equation, it can be written in terms of powers or the complex variables $r_{\pm} = x \pm iy$:

$$Z_{||}(\omega, \vec{r}, \vec{r}_0) = \sum_{m=0}^{\infty} [C_m(\omega, \vec{r}_0) r_+^m + D_m(\omega, \vec{r}_0) r_-^m], \quad (17)$$

From Eq.(16) follows the symmetry

$$D_m(\omega) = C_m^*(-\omega). \quad (18)$$

One can further express the coefficients C_m as a power series in \vec{r}_0 , and gets the impedance as a double infinite sum:

$$Z_{||}(\omega, \vec{r}, \vec{r}_0) = \sum_{m=1}^{\infty} \sum_{k=0}^{\infty} \left\{ [\alpha_{mk}(\omega) r_{0+}^k + \beta_{mk}(\omega) r_{0-}^k] r_+^m + [\alpha_{mk}^*(-\omega) r_{0-}^k + \beta_{mk}^*(-\omega) r_{0+}^k] r_-^m \right\}, \quad (19)$$

where $r_{0\pm} = x_0 \pm iy_0$. Contrary to the axi-symmetric case, this double sum, cannot be reduced to a single one.

For easier understanding, we now switch to the time domain.

4.2 Wake Function

We introduce the Fourier transforms of the coefficients

$$\begin{aligned}\alpha_{mk}(s) &= \int_{-\infty}^{\infty} \frac{d\omega}{2\pi} \alpha_{mk}(\omega) e^{-i\omega s/c}, \\ \beta_{mk}(s) &= \int_{-\infty}^{\infty} \frac{d\omega}{2\pi} \beta_{mk}(\omega) e^{-i\omega s/c},\end{aligned}\quad (20)$$

Hence the longitudinal wake function can be written

$$\begin{aligned}W_{\parallel}(s) &= \sum_{m=0}^{\infty} \sum_{k=0}^{\infty} [\alpha_{mk}(s)r_{0+}^k + \beta_{mk}(s)r_{0-}^k] r_+^m + \\ &\quad [\alpha_{mk}^*(s)r_{0-}^k + \beta_{mk}^*(s)r_{0+}^k] r_-^m.\end{aligned}\quad (21)$$

Similarly, the transverse wake function components become

$$\begin{aligned}W_x(s) &= \sum_{m=0}^{\infty} \sum_{k=0}^{\infty} m \left\{ [a_{mk}(s)r_{0+}^k + b_{mk}(s)r_{0-}^k] r_+^{m-1} + \right. \\ &\quad \left. [a_{mk}^*(s)r_{0-}^k + b_{mk}^*(s)r_{0+}^k] r_-^{m-1} \right\}, \\ W_y(s) &= \sum_{m=0}^{\infty} \sum_{k=0}^{\infty} im \left\{ [a_{mk}(s)r_{0+}^k + b_{mk}(s)r_{0-}^k] r_+^{m-1} - \right. \\ &\quad \left. [a_{mk}^*(s)r_{0-}^k + b_{mk}^*(s)r_{0+}^k] r_-^{m-1} \right\},\end{aligned}\quad (22)$$

where $\partial a_{mk}(s)/\partial s = -\alpha_{mk}(s)$ and $\partial b_{mk}(s)/\partial s = -\beta_{mk}(s)$.

From Maxwell's equations and the definition of the wake functions, one can derive the general relations

$$\frac{\partial W_x}{\partial x} = -\frac{\partial W_y}{\partial y}, \quad \frac{\partial W_x}{\partial y} = \frac{\partial W_y}{\partial x}\quad (23)$$

It can be verified that these equations are fulfilled by the above expressions.

4.2.1 Lowest Order Terms

Ordering the terms of equal powers in x, y and x_0, y_0 , one finds that the coefficients appear always in the combinations Re or Im ($\alpha_{mk} \pm \beta_{mk}$). We put $2 \text{Re} (\alpha_{mk} + \beta_{mk}) = C_{mk}$ and $2 \text{Im} (\alpha_{mk} + \beta_{mk}) = D_{mk}$. The difference terms are distinguished by a bar over the letter: $\bar{C}_{mk} = 2 \text{Re} (\alpha_{mk} - \beta_{mk})$ and $\bar{D}_{mk} = 2 \text{Im} (\alpha_{mk} - \beta_{mk})$.

Similar relations hold for the coefficients a_{mk} and b_{mk} , and we designate their combinations with small letters $c_{mk} = 2 \operatorname{Re} a_{mk} + b_{mk}$, $d_{mk} = 2 \operatorname{Im} a_{mk} + b_{mk}$, and the barred coefficients when the plus is replaced by a minus sign. The components of the wake functions can then be written:

$$\begin{aligned}
W_{\parallel}(s) &= C_{00} + (x_0 C_{01} + x C_{10}) - (y_0 \bar{D}_{01} + y D_{10}) + (x_0^2 - y_0^2) C_{02} - 2x_0 y_0 \bar{D}_{02} + \\
&\quad + x_0 (x C_{11} - y D_{11}) - y_0 (x \bar{D}_{11} + y \bar{C}_{11}) + (x^2 - y^2) C_{20} - 2xy D_{20} , \\
W_x(s) &= c_{10} + x_0 c_{11} + 2x c_{20} - y_0 \bar{d}_{11} - 2y d_{20} , \\
W_y(s) &= -d_{10} - x_0 d_{11} - 2x d_{20} - y_0 \bar{c}_{11} - 2y c_{20} .
\end{aligned} \tag{24}$$

4.3 Structures with Transverse Symmetries

Additional constraints are imposed if a structure has certain transverse symmetries. For mirror symmetry about the vertical (y, z) plane, one finds the condition

$$W_{\parallel}(x, x_0, y, y_0) = W_{\parallel}(-x, -x_0, y, y_0) . \tag{25}$$

Therefore terms in W_{\parallel} which are odd w.r.t. x and x_0 must vanish, hence $C_{00} = C_{02} = \bar{C}_{11} = C_{20} = D_{01} = D_{10} = 0$, with the same conditions on the coefficients c_{mk} and d_{mk} . The only terms left are:

$$\begin{aligned}
W_{\parallel}(s) &= C_{00} - y_0 \bar{D}_{01} - y \bar{D}_{10} + (x_0^2 - y_0^2) C_{02} + (x_0 x C_{11} - y_0 y \bar{C}_{11}) + (x^2 - y^2) C_{20} , \\
W_x(s) &= x_0 c_{11} + 2x c_{20} , \\
W_y(s) &= -d_{10} - y_0 \bar{c}_{11} - 2y c_{20} .
\end{aligned} \tag{26}$$

Hence W_x is independent of vertical offsets y and y_0 , while W_y is independent of the horizontal ones. W_x furthermore vanishes when both horizontal offsets x and x_0 are zero.

For mirror symmetry about the horizontal (x, z) plane one obtains the condition $W_{\parallel}(x, x_0, y, y_0) = W_{\parallel}(x, x_0, -y, -y_0)$ and hence quite analogously: similar expressions

$$\begin{aligned}
W_{\parallel}(s) &= C_{00} + x_0 C_{01} + x C_{10} + (x_0^2 - y_0^2) C_{02} + x_0 x C_{11} - y_0 y \bar{C}_{11} + (x^2 - y^2) C_{20} , \\
W_x(s) &= c_{10} + x_0 c_{11} + 2x c_{20} , \\
W_y(s) &= -y_0 \bar{c}_{11} - 2y c_{20} .
\end{aligned} \tag{27}$$

For structures with symmetry about both the horizontal (yz) and the vertical (xz) planes, the same equations hold but without the constant terms:

$$\begin{aligned}
W_{\parallel}(s) &= C_{00} + (x_0^2 - y_0^2)C_{02} + (x_0xC_{11} - y_0y\bar{C}_{11}) + (x^2 - y^2)C_{20} , \\
W_x(s) &= x_0c_{11} + 2xc_{20} , \\
W_y(s) &= -y_0\bar{c}_{11} - 2yc_{20} .
\end{aligned} \tag{28}$$

For symmetry w.r.t. rotation by 90° - which includes the case of symmetry about two orthogonal planes as well as that of circular symmetry - one finds

$$W_x(s) = x_0 \operatorname{Re} (b_{11}) \quad W_y(s) = y_0 \operatorname{Re} (b_{11}) . \tag{29}$$

In this case, the quadrupolar component of the field does not give a contribution, and the transverse wakes depend only on the offset of the leading particle in the corresponding plane.

For symmetry about the horizontal (xz) plane, the next order (sextupolar) terms are

$$\begin{aligned}
W_x(s) &= -2x_0y_0\bar{d}_{12} + 2(x_0y\bar{d}_{21} + y_0xd_{21}) + 6xy\bar{d}_{30} , \\
W_y(s) &= -2x_0y_0\bar{c}_{12} - 2(x_0yc_{21} + y_0xd_{21}) - 6xy\bar{d}_{30} .
\end{aligned} \tag{30}$$

They change sign with x, x_0 , but also with y, y_0 , hence they are equally valid for symmetry about the vertical (yz) plane. However, when a structure is symmetric w.r.t. both planes, W_x should be odd in x but even in y , and the opposite for W_y . Hence in that case all sextupolar terms are zero, and octupolar terms are the lowest non-vanishing corrections:

$$\begin{aligned}
W_x(s) &= -x_0(x_0^2 - 3y_0^2) c_{13} - 3x_0(x^2 - y^2) c_{31} + 6xyy_0\bar{d}_{31} , \\
W_y(s) &= y_0(x_0^2 - y_0^2) \bar{d}_{13} + 3y_0(x^2 - y^2) \bar{c}_{31} + 6x_0xyc_{31} .
\end{aligned} \tag{31}$$

For constant x_0, y_0 , and since the terms multiplied by $x^2 - y^2$ cancel when $x = y$, the most important correction occurs when the product xy is large, assuming that the coefficients c_{31} and \bar{d}_{31} do not vanish. This is in agreement with the distortion of the dipolar vector field which can be seen in Figs. 2b, 2c and 4b, 4c. The deviation of the vectors from the otherwise parallel (dipole) fields is largest in the upper right corners, where the product xy is maximum.

4.4 Structures with Longitudinal Symmetry

If the structure has longitudinal symmetry about the (xy) plane, the impedance must remain the same when source and field points are interchanged. Also the direction of particle motion should be inverted, but that is known to leave the impedance unchanged even in asymmetric structures[10]. Thus

$$\begin{aligned} Z_{\parallel}(\omega, \vec{r}, \vec{r}_0) &= Z_{\parallel}(\omega, \vec{r}_0, \vec{r}) . \\ W_{\parallel}(s, \vec{r}, \vec{r}_0) &= W_{\parallel}(s, \vec{r}_0, \vec{r}) . \end{aligned} \quad (32)$$

This relation is fulfilled if $\alpha_{km}(\omega) = \alpha_{mk}(\omega)$, $\beta_{km}(\omega) = \beta_{mk}^*(-\omega)$, and similarly $a_{km}(s) = a_{mk}(s)$, $b_{km}(s) = b_{mk}^*(s)$.

We therefore get the additional relations $c_{mk} = c_{km}$, $\bar{c}_{mk} = \bar{c}_{km}$, and $d_{mk} = \bar{d}_{km}$. To lowest order, we find the symmetry:

$$\frac{\partial W_x}{\partial y_0} = \frac{\partial W_y}{\partial x_0} , \quad (33)$$

but, contrary to Eq. (25), this useful relation is not generally valid.

5 Conclusions

In rotationally structures, the dominant $m = 0$ longitudinal impedance does not depend on the offsets of either the leading or the trailing particles, while the dominant $m = 1$ transverse impedance is proportional to the offset of the leading particles, while it is still independent of the offsets of the trailing ones. This behavior is no longer true in rotationally non-symmetric structures, where in general *all impedances depend on the offsets of both the leading and the trailing particles*. The same behavior is shown by wake functions and wake potentials. The concept of *generalized impedances* or *generalized wake functions* must be used to calculate the effect of leading particles on trailing ones with different offsets, each described by two transverse coordinates.

This dependence of wake potentials on four additional parameters (two for each offset) would make their use very cumbersome. Fortunately it was found that the transverse wake potentials can be separated into superpositions of *dipolar components*, which are proportional to the offset of the leading bunch, and *quadrupolar components*, which are proportional to the offset of the trailing particles. Higher multipole components are much smaller, and can be neglected for most structures without rotational symmetry.

In this report, we derive analytical expressions for these multipolar components, which permits estimates of the size of the neglected terms. In particular, when structures have one or two transverse symmetry planes, the expressions simplify and explain the behavior of wake potentials which had been computed for rotationally non-symmetric structures. The dipolar components are proportional only to the offset of the leading bunch, and the quadrupolar components only to that of the trailing one. Hence both components need to be computed only once for unit offset, and the total wake potentials can then be obtained by multiplication with the actual value of the offset and addition of them. For each spatial direction, only a one-dimensional array is needed, corresponding to the wake potential for unit offset as function of distance between the leading and trailing particles. This simplification saves a large amount of computer time and memory requirements, and is particularly useful for the simulation of coherent effects in single bunches where the wake potentials are only required over the bunch length. The computer simulation then needs only a small number of one-dimensional look-up tables to rapidly obtain the kicks due to wake potentials in all three spatial directions.

References

- [1] G. Nassibian, F. Sacherer, Nucl. Instr. Meth. 159 (1979), p.21-27
- [2] L. Palumbo, V. Vaccaro, Nuovo Cimento 89 A (1985), p.243-256
- [3] A. Piwinski, Report DESY 94-068 (1994)
- [4] K. Bane, private communication.
- [5] F. Ruggiero, CERN Report 95-95(1995)
- [6] W. Schnell, CLIC Note xxx (1986)
- [7] G. Sabbi, CERN Report 95-25 (1995)
- [8] A. Wagner, B. Zotter, Proc. EPAC 1996, p.1256-8
- [9] T. Weiland, NIMH 216 (1984) 31-34
- [10] R. Gluckstern, B. Zotter, CERN Report (1988)




Figure 1: Effective transverse wake potentials (kick factors) of 10 mm bunches in LEP bellows, for a centered beam (quadrupolar component) and with 4 mm offsets of the driving beam in x , y , and $x+y$.




Figure 2: Residual effective transverse wake potentials of 10 mm bunches in LEP bellows, obtained by subtracting quadrupolar component (fig.1a) from total wakes (figs.1b-d).




Figure 3: Effective transverse wake potentials (kick factors) of 10 mm bunches in LEP separators, for a centered beam (quadrupolar component) and with 4 mm offsets of the driving beam in x , y , and $x+y$.




Figure 4: Residual effective transverse wake potentials of 10 mm bunches in LEP separators, obtained by subtracting quadrupolar component (fig.3a) from total wakes (figs.3b-d).